



Quick Start Guide – Software

1. Install the software on your PC from this link:

<http://houston-radar.com/HoustonRadarStatsAnalyzerUpgrade v8.01.0026.msi>

<http://houston-radar.com/HoustonRadarStatsAnalyzerUpgrade.msi>

The software is also available on the disk supplied but some versions of Windows will not run the uploader from the disc. In this case connect the laptop to the Internet and either click on the link above or paste the link into your web browser.

2. Connect the download cable to the Laptop and allow it to download driver files for the smart cable. These files are also available on the SpeedSentry disc as:

CDM v2.12.00 WHQL Certified.exe

3. Click on the HoustonRadar icon that is placed on your laptop desktop, the Houston Radar software will load
4. Open the Houston Radar software, select "File", select "connect to radar"
5. At this point the connection window will open. Connect the smart cable to the radar (which must be switched on) and press the connect button in the software.
6. Press OK to complete the connection and enable full functionality.
7. Please refer to the full user guide for step by step instructions on the use of the software.